

## SERIES OF POLARIZED STRESS METER

# Polarized stress meter for PET preform PSV-801

### ➔ Equipment Application

Polarization principle is adopted to make qualitative observation and analysis on the internal stress of transparent PET preform and is widely used in quality control of PET rough processing products. Convenient to control products stress timely and ensure and improve the product quality.

### ➔ Application area

Suitable for the testing crystallization or other defects of colored and colorless transparent plastic bottles.

### ➔ Equipment Features

1. Crystallization or other defects of PET preform could be recognized visually.
2. In addition to detect transparent bottles of various colors, the equipment has 12 kinds of defect analysis functions, and provides solutions for various defects in the production process of the preform.

Technical parameter	
Polarizer size	200*200mm
Measuring space height	234.5mm
Dimensions	330*335*346mm
Power supply	220v
Light source	LED : White and sodium light

